

MINI CRANE SCALE

# USER GUIDE



MODEL: OCS- L

CE

# Content

<b>1. Introduction.....</b>	<b>1</b>
Notice.....	1
Safety Guide.....	1
<b>2. Specifications.....</b>	<b>2</b>
Features.....	2
Specifications .....	3
Capacity and Resolution .....	4
Schematic Diagram .....	4
Dimension .....	5
<b>3. Operation Guide.....</b>	<b>6</b>
Power On.....	6
Power Off.....	6
Tare.....	7
Hold .....	8
Unit Switch.....	8
Zero .....	9
Setting .....	9
<b>4. Trouble-shooting.....</b>	<b>12</b>
<b>5. Note.....</b>	<b>13</b>

# 1. Introduction

## Notice

**Before you use the scale, please read this manual through carefully, and keep it properly for future use.**

## Safety Guide

**For good performance and precise measurement, be careful with daily operation and maintenance. Note the following instructions:**

- ➡ Do **NOT** overload the scale. This will damage the loadcell and void the warranty.
- ➡ Do **NOT** leave load hung on the scale for long. This will decrease the scale's accuracy and shorten the loadcell's life.
- ➡ Inspect shackle and hook before using.
- ➡ When the scale runs out of power, replace the battery with full ones.
- ➡ Do **NOT** use the scale under thunder or rain.
- ➡ Do **NOT** attempt to repair the scale yourself. Contact your local representative.

## 2. Specifications

### Features

This scale is a combination of the sound and proven mechanical design, with today's most advanced electronics to provide a superb feature set. It is versatile, reliable, accurate and easy to operate.

<b>Superb Quality</b>	In accordance with OIML R76, GB/T11883-2002. ISO9001-2000 certified quality system.
<b>Great Safety</b>	Quality stainless steel load receptor and Aluminum-casting case for better safety.
<b>Newest Design</b>	20mm LCD, visual distance over 10m. Dismountable hook.
<b>Leading Technology</b>	SMT technology, quality integrated circuit and dedicated weighing loadcell, ensures long time stability.
<b>Smart Power-saving</b>	3*AA battery with low power consumption design.
<b>Portable</b>	Different color optional. Easy to carry.


## Specifications

Accuracy Class	Chinese GB/T 11883-2002 Class III Equivalent to OIML R76
Tare Range	100% F.S.
Auto Zero	± 50% F.S.
Manual Zero	± 2% F.S.
Zero-tracking	0.5e/s
Reading Stable Time	≤10 seconds
Auto-sleep	Sable and no action in 3 sec.
Auto-off	Sable and no action in 3 min.
Overload	100% F.S. + 9e
Max. Safety Load	120% F.S.
Ultimate Load	300% F.S.
Battery Life	>150 hours
Battery	3*AA (rechargeable) battery
Temp. (Op.)	- 10°C ~ + 40°C
Humidity (Op.)	≤90% at 20°C
Display	0.7 inch (17.78mm) numerical
Net Weight	620g


## Capacity and Resolution

Model	Max. Cap. (kg/lb)	E (kg/lb)	Division (n)
OCS-003-L	30/60	0.01/0.02	3,000
OCS-005-L	50/100	0.02/0.05	2,000
OCS-006-L	60/120	0.02/0.05	3,000
OCS-01-L	100/200	0.05/0.1	2,000
OCS-012-L	120/240	0.05/0.1	2,400
OCS-015-L	150/300	0.05/0.1	3,000
OCS-02-L	200/400	0.1/0.2	3,000
OCS-03-L	300/600	0.1/0.2	3,000

## Schematic Diagram





## Dimension




## 3. Operation Guide

### Power On

 Press  for 1 second to boots up, battery tests and initializes.



- Screen shows detection message while scale detects its load and auto-zero itself.



### Power Off

 Press  for 1 second to power off scale.



- Display shows power-off message.



## Tare



Press  to store weight as tare.



“TARE” shows and weight turns zero.



If weight is over 100%F.S., or less than 0, tare is not allowed.




If weight is not stable or held, tare is not allowed.




Taring will reduce scale's apparent overloading range. E.g., if a 10kg container is tared and scale's maximum capacity is 50kg, scale will overload at a new weight of 40.18kg (5000 – 1000 + additional 9 divisions).



Press  to restore tare.




“TARE” hides, and weight resumes in gross mode.



## Hold



Press  to lock the display.

- "HOLD" shows and display is frozen.




Press  again to resume display.

- "HOLD" hides and display resume refreshing.





## Unit Switch



Press  for 1 second to switch measuring unit between kg, lb and N.

- If scale is tared, or held, unit switching is not allowed.



## Zero



Press  for 1 second to zero scale.



“ZERO” shows and weight turns zero.



If weight is tared, or not stable, or held, zero is not allowed.





If weight is over Manual-Zero range, zero is not allowed.






## Setting



Press  and  simultaneously, and hold two buttons for 1 second, to enter Setting Mode.





Press  to enter Auto-Off option; and press  to change




Auto-Off option.

- Auto-Off can be set to 0 (disabled), 5 (5min), 15 (15min), 30 (30min), 60 (60min).






Press  to enter Auto-Zero option; and press  to change Auto-Zero option.



- Auto-Zero can be set to 0 (disabled), 2 (2%F.S.), 4 (4%F.S.), 10 (10%F.S.), 20 (20%F.S.), 50 (50%F.S.).





Press  to enter Manual-Zero option; and press  to change Manual-Zero option.



- Manual-Zero can also be set to 0 (disabled), 2 (2%F.S.), 4 (4%F.S.), 10 (10%F.S.), 20 (20%F.S.), 50 (50%F.S.).




Press  to enter Backlight option; and press  to change Backlight option.



- ☑ Backlight can be set to off (disabled), 5 (5sec), 15 (15sec), 30 (30sec), 60 (60sec), on (never).
- ☑ When Backlight is set to 5, 15, 30, or 60, scale turns off backlight in corresponding seconds after it is stable.
- ☑ When Backlight is set to off, backlight is disabled, and never turns on.
- ☑ When Backlight is set to on, scale never turns off backlight, no matter it is stable or not.



Press  to exit the Settings Mode.



## 4. Trouble-shooting

Symptom	Possible Causes	Solution
blank display when On/Off is pressed	discharged battery	replace battery
	defective battery	
	defective ON/OFF key	press ON/OFF key for long
no action taken after TARE or HOLD is pressed	defective TARE or HOLD key	clean TARE or HOLD key
unstable readings	scale in motion	stabilize the load and scale
	scale is damped	dry the scale
	dust on PCB board	clean PCB board
reading is not zero without load	unstable system power	longer warm-up time
	load-cell stressed too much or too long	hang the scale in storage
large error in weight reading	scale is not zeroed before loading	keep the scale unload and reboot
	re-calibration needed	re-calibrate the scale
	improper unit	switch to proper unit

## 5. Note