

USER GUIDE

1. Operation Guide

Power off:

- Press "ON/OFF" key to turn off under weighing mode.
- The electronic scales will auto turn off in 120 seconds if there is no operation.

Unit selection:

Press "UNIT" key to select the unit. The unit could be selected among kg/lb/oz.

Backlight function:

- Backlight will be extinguished after 5 seconds without any push button operation or weight be changed. Backlight will be illuminated when touch any push button or change the weight.

Weight Lock

- Press "ZERO" key for 2 seconds until the ON or OFF sign appearing on the screen.
- ON stands for weight lock which means weight of the article will be fixed on the screen.
- OFF stands for weight lock function disable.

1. Caution

- Vertical position required for turn on or self test.
- To keep the weight accuracy and protect the scale. Please hold the stationary ring straight or add some additional tools on the stationary rings when weighing.
- Avoid any strong shock or vibration during operation.
- Remove the batteries to avoid leakage and damage to the circuits if the scale is not used for a long time.
- Do not disassemble the scale yourself in case the product needs repair. Please contact our agent for assistant.